


Special Note



When connecting exterior assembly and interior assembly, make sure the Interior Knob and Tailpiece **MUST** be turned in VERTICAL position.

(Refer to installation manual section 6-8 for details)



Interior Knob
on interior assembly

Tailpiece
on exterior assembly



Turn to vertical position